





## HOW IT WORKS SOLARARK EVACUATED TUBE SYSTEM



**5. WATER GETS PUMPED FROM THE TANK TO THE EVACUATED TUBE COLLECTOR ON THE ROOF, HARNESSING HEAT COLLECTED FROM THE TUBES.**

**HOT WATER**

**AUSTRALIA'S HIGHEST PERFORMER**

[www.solarark.com.au](http://www.solarark.com.au)  
1300670966  
[info@solarark.com.au](mailto:info@solarark.com.au)

VENTILATION POWER HOT WATER AIR CONDITIONING